SEKURA®

Make loss prevention simpler,
safer and **Sekura**

📖 User Guide

Arc)Tag™

⚙ Applying the ArcTag™

1 Slide the opening onto the area of merchandise to be tagged ensuring the **clutch** is on the outside.

2 Press firmly on the red plunger. The item is now securely tagged!

🔧 Releasing the ArcTag™

1 Apply the clutch to the detacher. If the plunger does not release immediately, press the top firmly and it will be released.

2 Remove the released ArcTag™.