SEKURA®

Make loss prevention simpler, safer and **Sekura**

📖 User Guide

COMMANDER V2 DETACHER

COMMANDER V2 DETACHER MAIN FEATURES:

- Two Barrel Keys for locking.
- 3x 1" screws for surface mounting.
- Compatible with S3, Standard lock and Superlock systems.
- Enhanced S3 plastic locators durability.
- No lanyard tangling – enhanced ball swivel connection.

CAUTION: Extremely powerful magnet. Do not place magnetic media such as credit cards near the Commander Detacher as this may erase the magnetic strip.

NOTE: A4 TEMPLATE TO BE PRINTED AT 100% SIZE.

Main Detacher
S3 Compatible Detacher
Coated Steel Lanyard
Housing
Lock

⚙ Mounting

1 Select the location for the Commander V2 Detacher and mark screw positions using the base template on the back of this sheet. Drill pilot holes.

2 Remove the detacher from the housing to access the screw holes and fix down using the 1" screws.

3 Place the detacher back into the housing with the S3 compatible detacher and main detacher facing upwards. The Commander is ready to use.

🔒 Lock/Unlock

1 To lock: Place the detacher into the housing with the S3 compatible detacher and main detacher facing downwards.

2 Insert barrel key into lock and push down before turning clockwise a quarter turn.

1 To unlock: Insert barrel key into the lock and push down before turning counter-clockwise.

2 Remove the released detacher and rotate to place into the housing with S3 compatible detacher and main detacher facing upwards.

● **Screw Holes**

🔧 Base Template

**1** Place template on cash desk in desired location of Commander V2 Detacher.

2 Mark screw hole locations through sheet using the circular markings.

3 Remove template and drill pilot holes (ideally 1/16" diameter).

4 Place Commander V2 Detacher over pilot holes and screw securely to cash desk.

NOTE: A4 TEMPLATE TO BE PRINTED AT 100% SIZE.