

## LynxLoc™ **FLEX** + RECOILER

### Applying the LynxLoc™ FLEX




- 1** Pass the end of the lanyard through a secure part of the merchandise such as a handle or buckle.



- 2** Connect the lanyard tip into the opening of the LynxLoc™ FLEX casing.



- 3** Take the recoiler tip and prepare to insert into the bottom right hand side of the LynxLoc™ FLEX casing.



- 4** When the tip clicks into position, the LynxLoc™ FLEX is now locked and ready to merchandise.



Scan the QR code  
to watch the video  
on how to apply and  
release the  
LynxLoc™ FLEX



## 🔧 Releasing the LynxLoc™ FLEX

- 1** To release the recoiler first, place the clutch (on the right hand side of the case) onto the centre of the detacher.



- 2** Gently pull the lanyard to release it and disarm the recoiler.



- 3** To release the LynxLoc™ FLEX, place the clutch (bottom left) onto the centre of the detacher. Gently pull the lanyard out of the tag.



- 4** The merchandise is now ready to be sold.

