

## 🛄 User Guide

## OysterTag<sup>™</sup> + S3 Detacher

## ✿ Applying the OysterTag<sup>™</sup>

Insert the product into the Oyster Tag casing.







Close the yellow tag over the card tab and press the plunger to lock. The product is now ready to merchandise.



## ✓ Releasing the OysterTag<sup>™</sup>





Gillette

8.





Remove the product

2

from the Oyster Tag casing. The product is now ready to be sold.

