

## User Guide

# The Self-Retracting BoxGrip™



## Applying the Self-Retracting BoxGrip™



- 1 Position the merchandise on a flat surface. Expand the BoxGrip™ by pulling the locking mechanism away from the backing disc.



- 2 Place two of the cables over one corner of the box and wrap the other two around the other side.



- 3 Center the BoxGrip™ locking mechanism on the front of the product with one cable around each side of it.



- 4 To lock and arm the BoxGrip™ depress the lock button until there is a 'click' and confirmation 'beep'.



- 5 To secure, twist the bar firmly in a clockwise direction until cables are taut. Merchandise is now ready to be displayed.




This user guide is applicable to the **regular** and **XL** Self-Retracting BoxGrip™

## 🔧 Releasing the Self-Retracting BoxGrip™

The BoxGrip™ can be used with a variety of detachers, view the correct instructions for your detacher.

### S3 Key

- 1 Apply the detacher to the clutch on the locking mechanism and press the lock button until there is a 'click' and it pops out.



- 2 Pull away the BoxGrip™ from the merchandise and it will retract neatly ready for reuse.



### Commander Detacher

- 1 Apply the detacher to the clutch on the locking mechanism and press the lock button until there is a 'click' and it pops out.



- 2 Pull away the BoxGrip™ from the merchandise and it will retract neatly ready for reuse.



### MEGALOC™ Detacher

- 1 Hold the BoxGrip™ against the detacher with the lock button downwards. Push the BoxGrip™ lock button up against the wall of the detacher. A 'click' will sound as the lock releases.



- 2 Pull away the BoxGrip™ and it will retract neatly ready for reuse.

