

Ultra Tough Safers



Loading merchandise into safer


1 Open the safer by pulling apart.




2 Insert merchandise.



3 Close the safer.



4 Locate the sliding tab on the lock bar.
Slide it across to secure the safer.
Product is now ready to be displayed.



🔧 Releasing merchandise from safer

- 1 Place the lock bar onto the detacher.
There will be a 'click' as the lock releases.



- 2 If the safer does not unlock immediately,
slide the tab to unlock.



- 3 Open the two halves of the safer and
remove the merchandise.



- 4 Product is now ready to be sold.



WARNING: The **MEGALOC™** Detacher is a high powered magnet and can damage credit cards or other electronic devices if in close proximity.

People with pacemakers should exercise caution when using the **MEGALOC™** detacher.