

MEGALOC™ Universal Razor Blade Safer

Loading merchandise into safer



- 1** Open the safer by placing the clutch onto the detacher.



- 2** Once full open, place the blister pack on the flat back of the safer.



- 3** Close the safer firmly until a click is heard, meaning the clutch is engaged and fully locked.



Releasing merchandise from safer

1 When the safer is on the detacher, press the grey button next to the lock to release.

Note: The lock will automatically release without pressing the button on Black, Green, or Yellow button versions



2 Open the safer, and remove the blister pack.

