

## DIAMOND BASE Self-Retracting BoxGrip™



### Applying the Diamond Base SR BoxGrip™



- 1** Position the merchandise on a flat surface. Expand the Diamond Base SR BoxGrip™ by pulling the locking mechanism away from the backing disc. Ensure that the perspex diamonds are centrally positioned on the box sides.



- 2** Place two of the cables over one corner of the box and wrap the other two around the other side. Center the BoxGrip™ locking mechanism on the front of the product with one cable around each side of it.



- 3** To lock and arm the BoxGrip™ depress the lock button until there is a 'click' and confirmation 'beep'.



- 4** To secure, twist the bar firmly in a clockwise direction until cables are taut. Merchandise is now ready to be displayed.



## 🔧 Releasing the Diamond Base SR BoxGrip™

- 1 Place the box onto the desk mounted detacher with the Diamond Base SR BoxGrip™ underneath. Press the button until there is a 'click' and it pops out.



- 2 Pull away the Diamond Base SR BoxGrip™ from the merchandise and it will retract neatly ready for reuse.

